

LanTEKII & III Series Software Upgrade Instructions

1)



LT2_3xxx.ZIP



unzip



LT2_3xxx.IDL

2)



LT2_3xxx.IDL



copy




USB Stick

3)



4)



~ 2 min

Upgrade 

