



TREND NETWORKS

SignalTEK CT

Upgrade Information



SignalTEK CT Software Release Notes

Version 1.0.36 – September 2020

Added Japanese language to user interface.

SignalTEK CT Software Update Procedure

WARNING

All stored data will be removed from tester. Please back up all your stored data to USB memory key before upgrading. The upgrade is not reversible back to previous version.

To update the Near End Display Unit to the current latest software version:

1. Unzip the software update files to the root directory of a USB memory key
2. Ensure that the tester is connected to the mains power supply, or that the battery is fully charged
3. Switch the tester ON
4. Insert the USB memory key into the tester
5. Save any results stored in the tester (all data and settings will be lost following the software update)
6. From the HOME screen, select F3(SETUP) / SYSTEM / UPDATE
7. Select F1 (UPDATE)
8. Wait for the update to be completed

To update the Remote Unit to the current software version:

No update to remote handset for version 1.0.36

1. Copy the file SigTEK2.bin to the root directory of a USB memory key
2. Ensure that the tester is connected to the mains power supply, or that the battery is fully charged
3. With the tester switched OFF, insert the USB memory key into the tester
4. Press and hold the AutoTest button
5. Switch the tester ON. The LEDs will flash in sequence
6. Wait for the update to be completed, when the LEDs stop flashing.